



Sanitaire 5815 Upright Series Maintenance Guide

To keep your vacuum performing properly, focus on these three areas. Most issues come back to one of them.

Keep airflow clear

- Check for clogs in the hose, intake, and internal airflow path.
- Detach the hose and inspect for blockages.
- Use a flashlight to check for hidden clogs and clear any obstructions gently with a flexible tool.

Even partial blockages will reduce suction and can lead to overheating.

Maintain bags and filters

- Restricted airflow is often caused by a full bag or dirty filters.
- Replace the bag when it's about half to two-thirds full.
- Clean or replace filters regularly, and if washing filters, always ensure they are completely dry before reinstalling.

This is one of the most common causes of performance issues.

Check the brush roll and belt

- If the vacuum is running but not cleaning, this is usually the reason.
 - Inspect the brush roll for debris like hair or string and remove any obstructions.
 - Make sure the brush spins freely and replace worn brushes or damaged belts as needed.
-

Additional quick checks

- Inspect the power cord for damage.
 - Set the correct brush height for the floor type.
 - Store the vacuum in a clean, dry area.
 - Avoid vacuuming salt—it can corrode internal parts over time.
 - Avoid vacuuming water or wet mats—it can damage the motor and cause internal corrosion.
-

Need Additional Help?

If you're still experiencing problems or have questions about maintaining your vacuum, Tennier Sanitation is here to help. For expert advice, troubleshooting, or product support, please reach out anytime.

Contact Us:

Phone: 905-522-5756

Email: email@tennier.ca

We're here to help you keep your equipment running at its best.